

## 3D model control in Processing / MPU Teapot

<http://www.youtube.com/watch?v=74xL-VcRyjQ>

Arduino Board  
(1) MPU-9150 Motion Tracking Device

MPU-9150 GRD > Arduino Ground  
MPU-9150 VCC > Arduino 3.3 VOLT  
MPU-9150 SDA > Arduino pin A4  
MPU-9150 SCL > Arduino pin A5  
MPU-9150 INT > Arduino pin 2

```
// I2C device class (I2Cdev) demonstration Arduino sketch for MPU6050 class using  
DMP (MotionApps v2.0)  
// 6/21/2012 by Jeff Rowberg <jeff@rowberg.net>  
// Updates should (hopefully) always be available at https://github.com/jrowberg/  
i2cdevlib
```

```
// Changelog:
```

```
// 2012-06-21 - added note about Arduino 1.0.1 + Leonardo compatibility error  
// 2012-06-20 - improved FIFO overflow handling and simplified read process  
// 2012-06-19 - completely rearranged DMP initialization code and simplification  
// 2012-06-13 - pull gyro and accel data from FIFO packet instead of reading directly  
// 2012-06-09 - fix broken FIFO read sequence and change interrupt detection to RISING  
// 2012-06-05 - add gravity-compensated initial reference frame acceleration output  
// - add 3D math helper file to DMP6 example sketch  
// - add Euler output and Yaw/Pitch/Roll output formats  
// 2012-06-04 - remove accel offset clearing for better results (thanks Sungon Lee)  
// 2012-06-01 - fixed gyro sensitivity to be 2000 deg/sec instead of 250  
// 2012-05-30 - basic DMP initialization working
```

```
/* =====
```

```
I2Cdev device library code is placed under the MIT license  
Copyright (c) 2012 Jeff Rowberg
```

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

```
=====
```

```
*/
```

## ARDUINO CODE

```
// Arduino Wire library is required if I2Cdev I2CDEV_ARDUINO_WIRE
// implementation is used in I2Cdev.h
#include "Wire.h"

// I2Cdev and MPU6050 must be installed as libraries, or else the
// .cpp/.h files
// for both classes must be in the include path of your project
#include "I2Cdev.h"

#include "MPU6050_6Axis_MotionApps20.h"
// #include "MPU6050.h" // not necessary if using MotionApps include
// file

// class default I2C address is 0x68 specific I2C addresses may be
// passed as a parameter here
// AD0 low = 0x68 (default for SparkFun and InvenSense evaluation
// board)
// AD0 high = 0x69
MPU6050 mpu;

/* =====
   NOTE: In addition to connection 3.3v, GND, SDA, and SCL, this
   sketch depends on the MPU-6050's INT pin being connected to the Ar-
   duino's external interrupt #0 pin. On the Arduino Uno and Mega 2560,
   this is digital I/O pin 2.
   * =====*/

/* =====
   NOTE: Arduino v1.0.1 with the Leonardo board generates a compile
   error when using Serial.write(buf, len). The Teapot output uses this
   method. The solution requires a modification to the Arduino USBAPI.h
   file, which is fortunately simple, but annoying. This will be fixed in the
   next IDE release. For more info, see these links:
   http://arduino.cc/forum/index.php/topic,109987.0.html
   http://code.google.com/p/arduino/issues/detail?id=958
   * =====*/

// uncomment "OUTPUT_READABLE_QUATERNION" if you want to see the actual
// quaternion components in a [w, x, y, z] format (not best for parsing
// on a remote host such as Processing or something though)
// #define OUTPUT_READABLE_QUATERNION

// uncomment "OUTPUT_READABLE_EULER" if you want to see Euler angles
// (in degrees) calculated from the quaternions coming from the FIFO.
// Note that Euler angles suffer from gimbal lock (for more info, see
// http://en.wikipedia.org/wiki/Gimbal_lock)
// #define OUTPUT_READABLE_EULER

// uncomment "OUTPUT_READABLE_YAWPITCHROLL" if you want to
// see the yaw/
// pitch/roll angles (in degrees) calculated from the quaternions coming
// from the FIFO. Note this also requires gravity vector calculations.
// Also note that yaw/pitch/roll angles suffer from gimbal lock (for
// more info, see: http://en.wikipedia.org/wiki/Gimbal_lock)
// #define OUTPUT_READABLE_YAWPITCHROLL

// uncomment "OUTPUT_READABLE_REALACCEL" if you want to see acceleration
// components with gravity removed. This acceleration reference frame is
// not compensated for orientation, so +X is always +X according to the
// sensor, just without the effects of gravity. If you want acceleration
// compensated for orientation, use OUTPUT_READABLE_WORLDACCEL instead.
// #define OUTPUT_READABLE_REALACCEL

// uncomment "OUTPUT_READABLE_WORLDACCEL" if you want to see acceleration
// components with gravity removed and adjusted for the world frame of
// reference (yaw is relative to initial orientation, since no magnetometer
// is present in this case). Could be quite handy in some cases.
// #define OUTPUT_READABLE_WORLDACCEL

// uncomment "OUTPUT_TEAPOT" if you want output that matches the
// format used for the InvenSense teapot demo
#define OUTPUT_TEAPOT

#define LED_PIN 13 // (Arduino is 13, Teensy is 11, Teensy++ is 6)
bool blinkState = false;
```

## ARDUINO CODE

```
// MPU control/status vars
bool dmpReady = false; // set true if DMP init was successful
uint8_t mpuIntStatus; // holds actual interrupt status byte from MPU
uint8_t devStatus; // return status after each device operation (0 = success, !=0
= error)
uint16_t packetSize; // expected DMP packet size (default is 42 bytes)
uint16_t fifoCount; // count of all bytes currently in FIFO
uint8_t fifoBuffer[64]; // FIFO storage buffer

// orientation/motion vars
Quaternion q; // [w, x, y, z] quaternion container
VectorInt16 aa; // [x, y, z] accel sensor measurements
VectorInt16 aaReal; // [x, y, z] gravity-free accel sensor measurements
VectorInt16 aaWorld; // [x, y, z] world-frame accel sensor measurements
VectorFloat gravity; // [x, y, z] gravity vector
float euler[3]; // [psi, theta, phi] Euler angle container
float ypr[3]; // [yaw, pitch, roll] yaw/pitch/roll container and gravity vector

// packet structure for InvenSense teapot demo
uint8_t teapotPacket[14] = { '$', 0x02, 0,0, 0,0, 0,0, 0,0, 0x00, 0x00, '\r',
'\n' };

// =====
// == INTERRUPT DETECTION ROUTINE ==
// =====

// indicates whether MPU interrupt pin has gone high
volatile bool mpuInterrupt = false;

void dmpDataReady() {
    mpuInterrupt = true;
}

// =====
// == INITIAL SETUP ==
// =====

void setup() {
    // join I2C bus (I2Cdev library doesn't do this automatically)
    Wire.begin();

    // initialize serial communication
    // (115200 chosen because it is required for Teapot Demo output, but it's
    // really up to you depending on your project)
    Serial.begin(115200);
    while (!Serial); // wait for Leonardo enumeration, others continue immediately

    // NOTE: 8MHz or slower host processors, like the Teensy @ 3.3v or Arduino
    // Pro Mini running at 3.3v, cannot handle this baud rate reliably due to
    // the baud timing being too misaligned with processor ticks. You must use
    // 38400 or slower in these cases, or use some kind of external separate
    // crystal solution for the UART timer.

    // initialize device
    Serial.println(F("Initializing I2C devices..."));
    mpu.initialize();

    // verify connection
    Serial.println(F("Testing device connections..."));
    Serial.println(mpu.testConnection() ? F("MPU6050 connection successful")
: F("MPU6050 connection failed"));

    // wait for ready
    Serial.println(F("\nSend any character to begin DMP programming and
demo: "));
    while (Serial.available() && Serial.read()); // empty buffer
    while (!Serial.available()); // wait for data
    while (Serial.available() && Serial.read()); // empty buffer again

    // load and configure the DMP
    Serial.println(F("Initializing DMP..."));
    devStatus = mpu.dmpInitialize();
```

## ARDUINO CODE

```
// make sure it worked (returns 0 if so)
if (devStatus == 0) {
    // turn on the DMP, now that it's ready
    Serial.println(F("Enabling DMP..."));
    mpu.setDMPEnabled(true);

    // enable Arduino interrupt detection
    Serial.println(F("Enabling interrupt detection (Arduino
external interrupt 0)..."));
    attachInterrupt(0, dmpDataReady, RISING);
    mpuIntStatus = mpu.getIntStatus();

    // set our DMP Ready flag so the main loop() function knows it's
okay to use it
    Serial.println(F("DMP ready! Waiting for first inter-
rupt..."));
    dmpReady = true;

    // get expected DMP packet size for later comparison
    packetSize = mpu.dmpGetFIFOPacketSize();
} else {
    // ERROR!
    // 1 = initial memory load failed
    // 2 = DMP configuration updates failed
    // (if it's going to break, usually the code will be 1)
    Serial.print(F("DMP Initialization failed (code "));
    Serial.print(devStatus);
    Serial.println(F(")"));
}

// configure LED for output
pinMode(LED_PIN, OUTPUT);
}

// =====
// ==                                MAIN PROGRAM LOOP                                ==
// =====

void loop() {
    // if programming failed, don't try to do anything
    if (!dmpReady) return;

    // wait for MPU interrupt or extra packet(s) available
    while (!mpuInterrupt && fifoCount < packetSize) {
        // other program behavior stuff here
        // if you are really paranoid you can frequently test in between other
        // stuff to see if mpuInterrupt is true, and if so, "break;" from the
        // while() loop to immediately process the MPU data
    }

    // reset interrupt flag and get INT_STATUS byte
    mpuInterrupt = false;
    mpuIntStatus = mpu.getIntStatus();

    // get current FIFO count
    fifoCount = mpu.getFIFOCount();

    // check for overflow (this should never happen unless our code is
too inefficient)
    if ((mpuIntStatus & 0x10) || fifoCount == 1024) {
        // reset so we can continue cleanly
        mpu.resetFIFO();
        Serial.println(F("FIFO overflow!"));
    }

    // otherwise, check for DMP data ready interrupt (this should happen
frequently)
    } else if (mpuIntStatus & 0x02) {
        // wait for correct available data length, should be a VERY short
wait
        while (fifoCount < packetSize) fifoCount = mpu.getFIFO-
Count();
    }
```

## ARDUINO CODE

```
// read a packet from FIFO
mpu.getFIFOBytes(fifoBuffer, packetSize);

// track FIFO count here in case there is > 1 packet available
// (this lets us immediately read more without waiting for an
interrupt)
fifoCount -= packetSize;

#ifdef OUTPUT_READABLE_QUATERNION
// display quaternion values in easy matrix form: w x y z
mpu.dmpGetQuaternion(&q, fifoBuffer);
Serial.print("quat\t");
Serial.print(q.w);
Serial.print("\t");
Serial.print(q.x);
Serial.print("\t");
Serial.print(q.y);
Serial.print("\t");
Serial.println(q.z);
#endif

#ifdef OUTPUT_READABLE_EULER
// display Euler angles in degrees
mpu.dmpGetQuaternion(&q, fifoBuffer);
mpu.dmpGetEuler(euler, &q);
Serial.print("euler\t");
Serial.print(euler[0] * 180/M_PI);
Serial.print("\t");
Serial.print(euler[1] * 180/M_PI);
Serial.print("\t");
Serial.println(euler[2] * 180/M_PI);
#endif

#ifdef OUTPUT_READABLE_YAWPITCHROLL
// display Euler angles in degrees
mpu.dmpGetQuaternion(&q, fifoBuffer);
mpu.dmpGetGravity(&gravity, &q);
mpu.dmpGetYawPitchRoll(ypr, &q, &gravity);
Serial.print("ypr\t");
Serial.print(ypr[0] * 180/M_PI);
Serial.print("\t");
Serial.print(ypr[1] * 180/M_PI);
Serial.print("\t");
Serial.println(ypr[2] * 180/M_PI);
#endif

#ifdef OUTPUT_READABLE_REALACCEL
// display real acceleration, adjusted to remove gravity
mpu.dmpGetQuaternion(&q, fifoBuffer);
mpu.dmpGetAccel(&aa, fifoBuffer);
mpu.dmpGetGravity(&gravity, &q);
mpu.dmpGetLinearAccel(&aaReal, &aa, &gravity);
Serial.print("areal\t");
Serial.print(aaReal.x);
Serial.print("\t");
Serial.print(aaReal.y);
Serial.print("\t");
Serial.println(aaReal.z);
#endif

#ifdef OUTPUT_READABLE_WORLDACCEL
// display initial world-frame acceleration, adjusted to remove
gravity
// and rotated based on known orientation from quaternion
mpu.dmpGetQuaternion(&q, fifoBuffer);
mpu.dmpGetAccel(&aa, fifoBuffer);
mpu.dmpGetGravity(&gravity, &q);
mpu.dmpGetLinearAccelInWorld(&aaWorld, &aaReal,
&q);
```

## ARDUINO CODE

```
Serial.print("aworld\t");
Serial.print(aaWorld.x);
Serial.print("\t");
Serial.print(aaWorld.y);
Serial.print("\t");
Serial.println(aaWorld.z);
#endif

#ifdef OUTPUT_TEAPOT
// display quaternion values in InvenSense Teapot demo
format:
    teapotPacket[2] = fifoBuffer[0];
    teapotPacket[3] = fifoBuffer[1];
    teapotPacket[4] = fifoBuffer[4];
    teapotPacket[5] = fifoBuffer[5];
    teapotPacket[6] = fifoBuffer[8];
    teapotPacket[7] = fifoBuffer[9];
    teapotPacket[8] = fifoBuffer[12];
    teapotPacket[9] = fifoBuffer[13];
    Serial.write(teapotPacket, 14);
    teapotPacket[11]++; // packetCount, loops at 0xFF on
purpose
#endif

// blink LED to indicate activity
blinkState = !blinkState;
digitalWrite(LED_PIN, blinkState);
}
}
```

## PROCESSING CODE

```
// I2C device class (I2Cdev) demonstration
Processing sketch for MPU6050 DMP output
// 6/20/2012 by Jeff Rowberg <jeff@rowberg.
net>
// Updates should (hopefully) always be available
at https://github.com/jrowberg/i2cdevlib
//
// Changelog:
// 2012-06-20 - initial release
```

```
/* =====
=====
I2Cdev device library code is placed under the
MIT license
Copyright (c) 2012 Jeff Rowberg
```

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

```
=====
=====
*/
```

```
import processing.serial.*;
import processing.opengl.*;
import toxi.geom.*;
import toxi.processing.*;

// NOTE: requires ToxicLibs to be installed in order to run properly.
// 1. Download from http://toxiclibs.org/downloads
// 2. Extract into [userdir]/Processing/libraries
// (location may be different on Mac/Linux)
// 3. Run and bask in awesomeness

ToxiclibsSupport gfx;

Serial port; // The serial port
char[] teapotPacket = new char[14]; // InvenSense Teapot packet
int serialCount = 0; // current packet byte position
int aligned = 0;
int interval = 0;

float[] q = new float[4];
Quaternion quat = new Quaternion(1, 0, 0, 0);

float[] gravity = new float[3];
float[] euler = new float[3];
float[] ypr = new float[3];

void setup() {
    // 300px square viewport using OpenGL rendering
    size(300, 300, OPENGL);
    gfx = new ToxiclibsSupport(this);

    // setup lights and antialiasing
    lights();
    smooth();

    // display serial port list for debugging/clarity
    println(Serial.list());

    // get the first available port (use EITHER this OR the specific port code below)
    String portName = Serial.list()[2];

    // get a specific serial port (use EITHER this OR the first-available code above)
    //String portName = "COM4";

    // open the serial port
    port = new Serial(this, portName, 115200);

    // send single character to trigger DMP init/start
    // (expected by MPU6050_DMP6 example Arduino sketch)
    port.write('r');
}

void draw() {
    if (millis() - interval > 1000) {
        // resend single character to trigger DMP init/start
        // in case the MPU is halted/reset while applet is running
        port.write('r');
        interval = millis();
    }

    // black background
    background(0);
    // translate everything to the middle of the viewport
    pushMatrix();
    translate(width / 2, height / 2);

    // 3-step rotation from yaw/pitch/roll angles (gimbal lock!)
    // ...and other weirdness I haven't figured out yet
    //rotateY(-ypr[0]);
    //rotateZ(-ypr[1]);
    //rotateX(-ypr[2]);
}
```

## PROCESSING CODE

```
// toxiCLibs direct angle/axis rotation from quaternion (NO gimbal lock!)
// (axis order [1, 3, 2] and inversion [-1, +1, +1] is a consequence of
// different coordinate system orientation assumptions between Processing
// and InvenSense DMP)
float[] axis = quat.toAxisAngle();
rotate(axis[0], -axis[1], axis[3], axis[2]);

// draw main body in red
fill(255, 0, 0, 200);
box(10, 10, 200);

// draw front-facing tip in blue
fill(0, 0, 255, 200);
pushMatrix();
translate(0, 0, -120);
rotateX(PI/2);
drawCylinder(0, 20, 20, 8);
popMatrix();

// draw wings and tail fin in green
fill(0, 255, 0, 200);
beginShape(TRIANGLES);
vertex(-100, 2, 30); vertex(0, 2, -80); vertex(100, 2, 30);
// wing top layer
vertex(-100, -2, 30); vertex(0, -2, -80); vertex(100, -2, 30);
// wing bottom layer
vertex(-2, 0, 98); vertex(-2, -30, 98); vertex(-2, 0, 70);
// tail left layer
vertex(2, 0, 98); vertex(2, -30, 98); vertex(2, 0, 70);
// tail right layer
endShape();
beginShape(QUADS);
vertex(-100, 2, 30); vertex(-100, -2, 30); vertex(0, -2, -80); vertex(
0, 2, -80);
vertex(100, 2, 30); vertex(100, -2, 30); vertex(0, -2, -80); vertex(
0, 2, -80);
vertex(-100, 2, 30); vertex(-100, -2, 30); vertex(100, -2, 30); vertex(
100, 2, 30);
vertex(-2, 0, 98); vertex(2, 0, 98); vertex(2, -30, 98); vertex(-2,
-30, 98);
vertex(-2, 0, 98); vertex(2, 0, 98); vertex(2, 0, 70); vertex(-2,
0, 70);
vertex(-2, -30, 98); vertex(2, -30, 98); vertex(2, 0, 70); vertex(-2,
0, 70);
endShape();

popMatrix();
}

void serialEvent(Serial port) {
  interval = millis();
  while (port.available() > 0) {
    int ch = port.read();
    print((char)ch);
    if (aligned < 4) {
      // make sure we are properly aligned on a 14-byte packet
      if (serialCount == 0) {
        if (ch == '$') aligned++; else aligned = 0;
      } else if (serialCount == 1) {
        if (ch == 2) aligned++; else aligned = 0;
      } else if (serialCount == 12) {
        if (ch == '\r') aligned++; else aligned = 0;
      } else if (serialCount == 13) {
        if (ch == '\n') aligned++; else aligned = 0;
      }
      //println(ch + " " + aligned + " " + serialCount);
      serialCount++;
      if (serialCount == 14) serialCount = 0;
    } else {
```



## PROCESSING CODE

```
if (serialCount > 0 || ch == '$') {
    teapotPacket[serialCount++] = (char)ch;
    if (serialCount == 14) {
        serialCount = 0; // restart packet byte position

        // get quaternion from data packet
        q[0] = ((teapotPacket[2] << 8) | teapotPacket[3]) / 16384.0f;
        q[1] = ((teapotPacket[4] << 8) | teapotPacket[5]) / 16384.0f;
        q[2] = ((teapotPacket[6] << 8) | teapotPacket[7]) / 16384.0f;
        q[3] = ((teapotPacket[8] << 8) | teapotPacket[9]) / 16384.0f;
        for (int i = 0; i < 4; i++) if (q[i] >= 2) q[i] = -4
+ q[i];

        // set our totilibs quaternion to new data
        quat.set(q[0], q[1], q[2], q[3]);

        /*
        // below calculations unnecessary for orientation only
        using totilibs

        // calculate gravity vector
        gravity[0] = 2 * (q[1]*q[3] - q[0]*q[2]);
        gravity[1] = 2 * (q[0]*q[1] + q[2]*q[3]);
        gravity[2] = q[0]*q[0] - q[1]*q[1] - q[2]*q[2] +
q[3]*q[3];

        // calculate Euler angles
        euler[0] = atan2(2*q[1]*q[2] - 2*q[0]*q[3],
2*q[0]*q[0] + 2*q[1]*q[1] - 1);
        euler[1] = -asin(2*q[1]*q[3] + 2*q[0]*q[2]);
        euler[2] = atan2(2*q[2]*q[3] - 2*q[0]*q[1],
2*q[0]*q[0] + 2*q[3]*q[3] - 1);

        // calculate yaw/pitch/roll angles
        ypr[0] = atan2(2*q[1]*q[2] - 2*q[0]*q[3], 2*q[0]*q[0]
+ 2*q[1]*q[1] - 1);
        ypr[1] = atan(gravity[0] / sqrt(gravity[1]*gravity[1] +
gravity[2]*gravity[2]));
        ypr[2] = atan(gravity[1] / sqrt(gravity[0]*gravity[0] +
gravity[2]*gravity[2]));

        // output various components for debugging
        //println("q:\t" + round(q[0]*100.0f)/100.0f + "\t" +
round(q[1]*100.0f)/100.0f + "\t" + round(q[2]*100.0f)/100.0f + "\t"
+ round(q[3]*100.0f)/100.0f);
        //println("euler:\t" + euler[0]*180.0f/PI + "\t" +
euler[1]*180.0f/PI + "\t" + euler[2]*180.0f/PI);
        //println("ypr:\t" + ypr[0]*180.0f/PI + "\t" +
ypr[1]*180.0f/PI + "\t" + ypr[2]*180.0f/PI);
        */
    }
}

}

}

void drawCylinder(float topRadius, float bottomRadius, float
tall, int sides) {
    float angle = 0;
    float angleIncrement = TWO_PI / sides;
    beginShape(QUAD_STRIP);
    for (int i = 0; i < sides + 1; ++i) {
        vertex(topRadius*cos(angle), 0, topRadius*sin(angle));
        vertex(bottomRadius*cos(angle), tall,
bottomRadius*sin(angle));
        angle += angleIncrement;
    }
    endShape();
}
```

## PROCESSING CODE

```
// If it is not a cone, draw the circular top cap
if (topRadius != 0) {
    angle = 0;
    beginShape(TRIANGLE_FAN);

    // Center point
    vertex(0, 0, 0);
    for (int i = 0; i < sides + 1; i++) {
        vertex(topRadius * cos(angle), 0, topRadius *
sin(angle));
        angle += angleIncrement;
    }
    endShape();
}

// If it is not a cone, draw the circular bottom cap
if (bottomRadius != 0) {
    angle = 0;
    beginShape(TRIANGLE_FAN);

    // Center point
    vertex(0, tall, 0);
    for (int i = 0; i < sides + 1; i++) {
        vertex(bottomRadius * cos(angle), tall, bottomRadius
* sin(angle));
        angle += angleIncrement;
    }
    endShape();
}
}
```