



Odometer/Trip Meter

The odometer shows the total number of kilometers or miles your vehicle has been driven.

The trip meter shows the number of kilometers or miles driven since you last reset it.

Speedometer

This shows your speed in kilometers per hour (km/h) and/or miles per hour (mph) depending on the type.

Tachometer

The tachometer shows the engine speed in revolutions per minute (rpm). To protect the engine from damage, never drive with the tachometer needle in the red zone.